

TEXAS TRUCK RACKS

Ford Transit Connect, Nissan NV200/Chev City, Ram Promaster City Express Ladder Rack Installation Guidelines

These items are common to the Transit Connect, Nissan NV200/Chev City, and Ram Promaster City Express.

- **2 - Round Tube Cross Members w/ welded end plates/mounting supports.**
 - **1-Tube of clear silicone.**
 - **1-Ladder Stop**
 - **1-stainless U-Bolt.**
 - **2-stainless 5/16" flat washers**
 - **2-stainless 5/16" nylon insert lock nuts.**
-

Bolt Kit for Ford Transit Connect.

- **4-5/16 x 2 hex bolts** used to mount the stands to the roof.
 - **4 - 5/16" Plus Nuts** that mount to the roof attachment holes.
 - **4 - 5/16" flat washers** used in different locations.
 - **4 - 5/16" split lock washers** used with 5/16" bolts and flats.
 - **4-1x1x5 ½" plastic spacers** that mount between the mounting supports and roof.
-

Bolt Kit for Nissan NV200/Chev City.

- **4-8mm x 30mm stainless hex bolts**
 - **4-5/16 stainless flat washers**
 - **4-5/16 stainless split lock washers.**
 - **4-3/16 x 5 ½" plastic spacers** that mount between the mounting supports and roof.
-

Bolt Kit for Ram City Express.

- **8-6mm x 30mm stainless hex bolts**
- **8-1/4" stainless flat washers.**
- **8-1/4" stainless split lock washers.**
- **4-3/16 x 5 ½" plastic spacers** that mount between the mounting supports and the roof.

Ford Transit Connect

- **The cross members are the same length and will fit in either the front or rear mounting positions.**
 - **Remove the plastic tabs covering the holes in the roof of the van**
 - **Use a 7/16” drill bit and hand held drill to open up the holes in the van roof to allow insertion of the plus nuts(blind fasteners).**
 - **Be sure to completely set the plus nuts in the roof.**
 - **Place the plastic spacers between the roof and the stands, insert the 5/16” bolts with flat washers and split lock washers. Tighten all four bolts.**
 - **Apply clear silicone liberally around the stands and top of the bolts.**
 - **Use the U-Bolt to fasten the ladder stop to one of the cross members.**
-

Nissan NV/Chev City

- **The cross members are the same length and will fit in either the front or rear mounting positions.**
 - **Remove the plastic tabs covering the holes in the roof of the van.**
 - **Place the plastic spacers between the roof and the stands, insert the 8mm bolts with flat washers and split lock washers. Tighten all four bolts.**
 - **Apply clear silicone liberally around the stands and top of the bolts.**
 - **Use the U-Bolt to fasten the ladder stop to one of the cross members.**
-

Ram Promaster City Express

- **The cross members are the same length and will fit in either the front or rear mounting positions.**
- **Remove the plastic tabs covering the holes in the roof of the van.**
- **Place the plastic spacers between the roof and the stands, insert the 6mm bolts with flat washers and split lock washers. Tighten all eight bolts.**
- **Apply clear silicone liberally around the stands and top of the bolts.**
- **Use the U-Bolt to fasten the ladder stop to one of the cross members.**